


# APS-24.2

## Digital Message player



### Front view (FRS)

- |                      |                  |
|----------------------|------------------|
| 1 LED Indication     | 5 Treble control |
| 2 Sound source label | 6 Reset button   |
| 3 Volume control     | 7 Model code     |
| 4 Bass control       |                  |

### Description

#### Designation and function

Digital message player for the time controlled playback of audio files

#### Usable audio files

MP3

#### Configuration of the module

Via PC (Graphical User Interface GUI)


#### Use of the module

As independent audio source


#### Function of the module

- According to the programming of the APS-990 processor module
- According to the configuration of the module

RWS-24.1



RWS-59-LAN



### Rear view (RWS)

- |                    |
|--------------------|
| A External supply  |
| B PC/Network (LAN) |

#### Controls for volume, bass and treble

Do affect the tone in all active loudspeakers

#### Security

the operating knobs can be removed (with pliers) – operation only then possible with the aid of a screw-driver; an additional cover makes the operation impossible (prevents operating errors)

#### Rear panels (RWS)

- 1 × RWS-59-LAN (link to the PC)
- 1 × RWS-24.1 (option for external power supply)

**Technical specifications**

**Connection diagram for the DC socket (A)**

- 1 +10 VDC to +20 VDC
- 2 Ground



**Connection diagram for the RJ-45 socket (B)**

- 1 Transmit Data +
- 2 Transmit Data -
- 3 Receive Data +
- 4 Not connected
- 5 Not connected
- 6 Receive Data -
- 7 Not connected
- 8 Not connected



**Data**

**Removal of the module from a unit**

- a) CAUTION: the amplifier system must be disconnected from mains and battery supply!
- b) Remove the covering strips at the cabinet
- c) Unscrew the mounting screws
- d) Pulling out the module forwards

**Tasks of the module**

Time controlled playback of memorized MP3 files

**Operation of the module**

Combined with other APS components

**Use of the module**

On the input buses M1–M4 for playback

**Operation of the functions**

- Automatically according to the configuration
- Manually according to configuration

**Functions of the module**

According to the configuration of the module

**Priorities of the functions and activation of the AF**

According to the programming of the APS-990

**Data transfer between APS-24.2 and APS-990**

Via the DATA-S bus

**General information**

Frequency response	20 Hz to 20 kHz
Memory capacity	8 GB
Power supply external	10–20 VDC
Power consumption	5.10 VA
Wight (incl. RWS)	0.690 kg

**Power supply**

plug in both jumpers on the basic board (at R1) on the left

**Important**

The use must be in accordance with the programming!