



# APS-75

## Universal relay module



Front view (FRS)

1 Model code



Rear view (RWS)

A Connector block

### Description

#### Designation and function

Universal relay module with four potential-free change-over switches for the operation of external devices

#### Possible external devices

- Other systems
- Controls
- Relays
- Indication lamps
- Door openers

#### Activation of the relays

According to the programming of the APS-990 or APS-9000 processor module

#### Use of the module

Together with other APS components

#### Settings on the module


None

#### Rear panel (RWS)

RWS-75

**Technical specifications**

**Connection diagram for the connector block (A)**



**Data**

**Removal of the module from a unit**

- a) CAUTION: the amplifier system must be disconnected from mains and battery supply!
- b) Remove the covering strips at the cabinet
- c) Unscrew the mounting screws
- d) Pulling out the module forwards

**Task of the module**

Selective activation of the 4 relays

**Data transfer between APS-75 and the APS-990 or APS-9000**

Via the I<sup>2</sup>C bus

**Function of the module**

According to the programming of the APS-990 or APS-9000 processor module

**General informations**

Operating voltage of the relays	12 VDC
Load with 100 VAC	1.5 A
Constant load with 120 VAC	0.5 A
Constant load with 24 VDC	1.0 A
Constant load with 60 VDC	0.3 A

**Important**

The use must be in accordance with the programming!