


APS-86 | APS-88

Modules with sockets



Front view (FRS)

- | | |
|------------------------|-----------------|
| 1 Socket, individually | 3 Sockets CINCH |
| 2 Socket XLR 3-pole | 4 Model code |

Rear view (RWS)

- A Socket DIN 5-pole

Description

Designation and function

Module with front sockets for the front connection of additional equipment

Versions

- | | |
|--------|---|
| APS-86 | Module with 2 front sockets XLR |
| APS-88 | Module with 4 front sockets CINCH and 1 front socket XLR (optional) |

Use of the module

Together with other APS components

Settings on the module

None


Rear panel (RWS)

RWS-85

Technical specifications

Connection diagramm XLR socket (2)


- 1 Ground
- 2 NF sym. +
- 3 NF sym. -



Connection diagramm CINCH (3) socket

Standard:

- 1 Play left (Left In)
 - 2 Play right (Right In)
- Option:
- 3 Record left (Left Out)
 - 4 Record right (Right Out)



Connection diagramm DIN socket (A)

Corresponding with the used input module (connection 1:1)

